# K518PRO Versatile Key Programmer User Manual



 $\star$ Please read it carefully before operation, keep it well for further refer.

## Copyright

Lonsdor' s entire contents, including but not limited to products or services issued by itself or co-issued with cooperative companies, and the materials and software on Lonsdor' s related websites, are copyrighted and protected by law. No part of the above all shall be copies, modified, extracted, transmitted or bundled with other products, sold in any way or by any means without the permission of Lonsdor.

And infringement of the company's copyright and other intellectual property rights, Lonsdor shall seize its liability according to law!

## Disclaimer

K518 PRO key programmer and related info, which should be used only for normal vehicle maintenance, diagnosis and testing, please do not use it for illegal purposes.

Lonsdor shall not assume any incidental or consequential damages or any economic damages arising from the accidents of individual users and the 3rd parties, as well as legal responsibilities, due to their misuse, unauthorized change or repair of the device, or abuse to violate laws and regulations. The product has a certain degree of reliability, but does not rule out the possible loss and damage. The risk arising from the user at their own risk. Lonsdor does not assume any risks and responsibilities.

Declared by: Lonsdor Dept of Legal Affairs

Consdor

#### SAFETY INSTRUCTION

Before using this product, please read this instruction carefully to know how to use it properly.

(1) Do not hit, throw, acupuncture the product, and avoid falling, squeezing and bending it.

(2) Do not use this product in damp environment such as bathroom, and avoid it being soaked or rinsed with liquid. Please turn off the product in circumstances when it's forbidden to use, or if it may cause interference or danger.

(3) Do not use this product while driving a car, so as not to interfere with safety driving.

(4) In medical establishments, please follow the relevant regulations. In areas close to medical equipment, please turn off this product.

(5) Please turn off this product near high-precision electronic equipment, otherwise the equipment may malfunction.

(6) Do not disassemble this product and accessories without authorization. Only authorized institutions can repair it.

(7) Do not place this product and accessories in appliances with strong electromagnetic fields.

(8) Keep this product away from magnetic equipment. The radiation from magnetic equipment will erase the info/data stored in this product.

(9) Do not use this product in places with high temperature or inflammable air (such as near gas station).

(10) When using this product, please comply with relevant laws and regulations, and respect the privacy and legal rights of others.

Lonsdor

## **Table of Contents**

Copyright and Disclaimer1
Safety Instruction ······2
Contents
1. Registration Guide······4
2. Product Overview5
2.1 Introduction ·····5
2.2 Software/Hardware Advantages5
2.3 Function Superiority ······6
2.4 Specs and Parameter
2.5 Product List6
2.6 Product Appearance
2.6.1 K518 PRO Main Unit7
2.6.2 OBDII Connector+Cable8
2.6.3 Collect-simulate Antenna+J-LCD Cable10
2.6.4 KPROG Adaptor
2.7 Function Display ······12
2.7.1 Homepage Interface12
2.7.2 Special Functions Interface
2.7.3 System Settings Interface ••••••14
2.7.4 Function Operation Interface15
3. Aftersales Service 16
Warranty Card ······18

Consdor

#### **1. REGISTRATION GUIDE**

Note: after booting the device, please set and connect WIFI well, then go through the registration&activation process.

#### New user:

(1) For the first use, please prepare an available mobile phone or E-mail to help finish device registration and activation, click OK to start;

2 Boot the device and enter registration&activation process;

③ Enter user name, password, mobile number or E-mail to get verification code, then enter the code and submit registration;

- ④ New account is registered successfully, set the device's power-on password;
- ⑤ Submit the info, apply for binding the user to the device;
- 6 Verified by the server, successful registration;
- ⑦ Initialize menu and etc;
- (8) Reboot and enter the device system.

#### **Registered user:**

- (1) For the first use, please prepare the corresponding mobile phone or E-mail of the registered account to help finish device registration and activation, click OK to start;
- 2 Boot the device and enter registration&activation process;
- ③ Enter the registered mobile number or E-mail to get verification code, then enter the code and submit login;
- ④ Account login successful, set the device's power-on password;
- ⑤ Submit the info, apply for binding the user to the device;
- (6) Verified by the server, successful registration;
- ⑦ Initialize menu, etc;
- (8) Reboot and enter the device system.

### 2. PRODUCT OVERVIEW

#### 2.1 Introduction

Product Name: K518 PRO Versatile Key Programmer

**Product Description:** K518 PRO, 2nd generation product of K518, is a versatile key programming device released by Lonsdor, designed specifically for the technician and locksmiths. Integrated with all functions and features of its predecessor, this tablet device shows more advantages and functionality, including immobilization, odometer adjustment, remote/smart key generate, adaptor, chip identify and copy, key chip generate, remote frequency detect, ignition coil detect, Toyota smart key settings, one-key update, push function and etc.

#### 2.2 Software/Hardware Advantages

- $\checkmark$  Trendy tablet design with support frame, better user experience;
- $\checkmark$  Based on Android 9, more optimized operation;
- ✓ With Quad-core A7, the strongest computing power, 2 times that of A33;
- ✓ Excellent and powerful ultra-high energy consumption ratio;
- ✓ The first to support 8A(H chip) generation;
- $\checkmark\,$  Added support for CANFD and Ethernet protocols.

#### 2.3 Function Superiority

- $\checkmark\,$  More comprehensive functions and features based on K518;
- ✓ Support most car models on the market, luxury, domestic and popular cars all included;
- ✓ Networking/Pincode/OBD program, not required for most models;
- ✓ Support 24V lorry and heavy trucks.

#### 2.4 Specs and Parameter

Operation system: Android 9 Processor: Allwinner A50 Memory: Ram 2G flash 8G Display: MIPI 800\*1280 WiFi: (802.11 b/g/n) USB: USB2.0 Bluetooth: 4.1 SD card: support Plug & Unplug Battery: 5800MA Input voltage: 12V Shell material: PC hard shell+TPR60° Dimension: 26\* 3 \*16CM

<u>consdor</u><sup>®</sup>

#### 2.5 Product List

Name	Qty
K518 PRO Portable Bag	1
K518 PRO Main Unit	1
OBD II Connector	1set
12V Power Adaptor	1
Type-C USB Cable	1
Collect-Simulate Antenna	1
User Manual	1
Certificate	1

## 2.6 Product Appearance 2.6.1 K518 PRO Main Unit

按数字顺序: Trademark Capacitive Touch Screen Three-color Indicator Power-on/off Button Rubber Grip Homepage Button Setting Button Key Read & Identify Area Help Button Return Button

Power-on/off Button PS2 Port Collect-Simulate Antenna Port TYPE-C Port DC Charging Port DB15 Port TF Card Port Label Spring Steel Bracket 弹簧钢支架 Speaker

Lonsdor









K518 PRO主机整机介绍

2.6.2 OBDII Connector + Cable 按数字顺序: OBD Generic Plug Illuminated LOGO

Lonsdor

Lanyard Eyelet OBD Cable Type Sticker 蓝牙款 Bluetooth Ver 带线款 Cable Ver





蓝牙款

带线款

Lonsdor



OBDII转接线

DOIP转接线

## 2.6.3 Collect-simulate Antenna + L-JCD Cable(non-standard)



采集模拟天线

L-JCD线

consdor

#### 2.6.4 KPROG Adaptor(non-standard)

Trademark Three-color Indicator Simple Horn Seat

Power Interface DB25 Port USB Port



Lonsdor

## 2.7 Function Display

## 2.7.1 K518 PRO Homepage Interface



Function	Description
Immobilization	Program mechanical key/smart key/remote, etc. Support most of car models on the market, regular updates for new models
Odometer Adjustment	Mileage diagnosis and correction
Generate Remote/smart	Generate smart key/remote/garage door remote
Adaptor	Read and write EEPROM chip/CPU main control chip, read EEPROM Pincode, etc
Special Functions	Identify and copy key chip, generate key chip, detect remote frequency, simulate chip, decode chip, detect ignition coil, key settings, access control card, etc
Push Function	Push the designated function App to user, which will be automatically disabled when expired. Contact us to obtain function not activated yet
OBD Illumination	OBD connector's light can be switched on/off

Lonsdor

## 2.7.2 K518 PRO Special Functions Interface



Function	Description
Generate key chip	Support 4D, 46, 48, 7935, 8A and more key chip generation
Identify&Copy chip	Identify info and status of almost all car key chips on the market
Generate remote	Detect remote key's frequency
Simulate chip	Mainly LKE functions, include: simulate 4D/46/8A chip, bind LKE and obtain LKE info, etc
Decode chip	Support 46 and 4D chip decoding
Ignition coil	Detect if the coil has signal, also identify key type on AKL condition
Key settings	Set Lonsdor 8A and 4D smart key type
Unlock key	Unlock Toyota 8A smart key
Access control card	Identify and copy IC/ID card

Lonsdor



## 2.7.3 K518 PRO System Settings Interface

Function	Description
Wifi settings	Set WIFI connection
Ethernet	Display Ethernet card status, network connection status, MAC/IP address, etc
Bluetooth settings	Set Bluetooth connection status
Display settings	Set screen brightness and auto-off screen time
Start record	Click to start recording, or close demo video
Device info	View info like device ID, PSN, hardware/kernel version, etc
Screen test	Screen touch diagnosis
Bind adaptor	Require to bind the adaptor to the device for the first use
Reset device	Reset the device, situations like program error, system crash, communication failure, can be returned to normal state
Firmware upgrade	Update adaptor firmware

46%	<b>? ≏</b> 0.0V	防盗遥控匹配→	宝马→按系统分类	É→CAS4/CAS4+		
						演示
	生成启动钥匙	禁用钥匙	启用钥匙			反馈
						版本
	功能介绍	操作指引	注意事项	相关资料	•	

## 2.7.4 K518 PRO Function Operation Interface

Function	Illustrate each function, and necessary tips
Operation	Give concrete guide for each step, pics and notices attached if necessary
Attention	Emphasize tips and notices for functions, as well as user possible overlook during operation
Reference	Provide the basic info like chip type, frequency, car and key photos
?	Scan the code to view HELP instructions while programming key
Replay	System replay and user record process
Feedback	Feedback function problems in time
Version	Detect the latest version of current interface functions

Consdor

#### **3. AFTERSALES SERVICE**

(1) Our company will provide you with excellent after-sales service and warranty service within agreed time.

(2) The warranty period lasts 12 months since device activation date.

(3) Once the product is sold, the return and refund will not be accepted if there is no quality problem.

(4) For product maintenance beyond the warranty period, we will charge labor and material costs.

(5) If the device is faulty or damaged due to any of the following reasons, we reserve the right not to provide service based on the agreed terms (but you can choose paid service).

% The device and components are beyond the warranty period.

X Users find that the product appearance is flawed or damaged, but has no quality problem.

X Counterfeit, without certificate or invoice, our official back-end system can not authenticate the device info.

X The product is damaged due to not following the instructions in this manual for operation, use, storage, and maintenance.

\* Damage caused by private disassembly or damage caused by repair and maintenance of maintenance company unauthorized by Lonsdor.

X Liquid inflow, moisture, falling into water or mildewing.

X The newly purchased device works normally without any damage when unpacked for the first time. But with the prolonged time of use, screen damage occurs, such as screen explosion, scratching, white spots, black spots, silk screen, touch damage, etc.

% The use of special tools and accessories not provided by our company.% Force majeure.

X For the man-made damaged device, if you decide not to repair after we disassemble it and make a quotation, the device appears unstable condition (such as: unable to boot, crash, etc) when you receive it.

X Private cracking of the system causes function changes, instability, and quality damage.



(6) If the auxiliary parts and other parts (other than the main components of the device) are faulty, you can choose the paid repair service provided by our company or our authorized customer service outlets.

(7) We will perform repair after receiving your device and confirming its problems, so please fill in the problems in details.

(8) After repair finished, we will return the device to customer, so please fill in the correct delivery address and contact number.

(9) Customers who needs to send the device for repair, shall bear the cost, such as round-trip delivery cost, transportation cost and etc. If the device is damaged in the process of delivery, our company will not bear relevant fees. In particular cases, we will assist the customer to claim for compensation against the shipping company..

(10) We do not provide sales invoice to individual in any form. If need it, please ask the dealer you purchased from to invoice you.

(11) Please keep the warranty card properly, and fill in the card when returning your device for repair, so that we can deal with the relevant work procedures (the warranty card attached to the end of the manual).

(12) Aftersales service hotline: 400-966-9130

WeChat: guopi0001 guopi0004

Service hours: Monday to Sunday 9:00-12:00 13:30-18:00(legal holidays off). Website: www.lonsdor.com E-mail: service@lonsdor.com



Official account QR code



Official website QR code

<u>con</u>sdor<sup>®</sup>

Lonsdor

## **Product Warranty Card**

Customer name:	( Mr/Miss )
Phone No.:	
Customer address:	
Device model:	
Serial No.:	
Returned items (details):	
Problem description in details:	

Sending date:\_\_\_\_\_

(Note: our company reserves the final interpretation right for the above terms.)  $% \left( \left( {{{\left( {{{{\left( {{{{}}}}}} \right)}}}}\right(r + right)}} } \right)}} \right)} } \right)} }} \right)} }} } } \right)$